

Whiteboard Quick Start

Start Up

- Move the LCD Projector to the predetermined location
- Connect your computer to LCD Projector
- Turn On your Computer and the LCD Projector
- Plug in the PolyVision USB module
- Press Fn + F8
- Remove the cap from the PolyVision Pen

IMPORTANT:

The pen uses a small battery for power.

Whenever the cap is off, the battery is discharging.

REPLACE THE PEN CAP DURING LONG PERIODS OF NON USE

Starting EasiTeach Software

The whiteboard comes with a number of software programs.

Listed below are those programs installed on your computer



Whiteboard Quick Start

To access the EasiTeach software:

- Point to the Start Button
- Click 1 X
- Point to All Programs
- When the Menu appears – Point to RM EasiTeach
- Click on RMEasiTeach



Whiteboard Quick Start

Video Tutorial

Go to www.youtube.com

There are at least 20 tutorials on how to use the whiteboard.

In the Search Field type: polyvision

Click on any of the links to watch the videos.

